


 **RELIABLE**



1100CT

Brio Pro Steam Cleaner Trolley


1100CT Assembly Instructions




- | | |
|-------------------------|----------------------------------|
| 1. Base Unit | 9. Holder for accessories basket |
| 2. Rear Wheel (2x) | 10. Basket clamp (2x) |
| 3. Frontal Wheel | 11. Accessories basket |
| 4. Base Unit Clamp (2x) | 12. Wrench (2x) |
| 5. Screw (6x) | 13. Water Reservoir |
| 6. Washer (6x) | 14. Steam Cleaner Cap |
| 7. Nut (6x) | 15. Connection Pipe |
| 8. Handle | 16. Metal band for pipe (2x) |

Note: Always remove accessories basket (11) before steam cleaner, otherwise the trolley could fall back.


1. Ensure that all the components present in exploded view of your trolley is present in the box.
2. Use the two Wrench (12) to unscrew the upper nuts (7) of the base unit clamp (4) (both right/left sides) and remove the two correspondents screws (5) and the two washers (6).




3. Put into the base unit clamp the two ends of the handle (8), then place the two screws and nuts removed into previous point and tighten it by taking care of the position of the washers (6).




4. Slide the holder for accessories basket (9) into the position between the two basket clamps (10) and tight the two nuts.



5. Place the steam cleaner on the trolley and make sure that frontal wheels of the machine are on its right position (1).
6. Place accessories basket (11) into the holder (9).
7. Screw the Steam Cleaner Cap (14) on machine's water tank.



8. Put water reservoir (13) into the holder, then fit the pipe (15) on the steam clean cap (14) and on the hose tail of water reservoir, tight the metal band (16) on both hose tails.



Warranty Coverage

Reliable Corporation ("Reliable") offers a **one-year** warranty for the original purchaser of its products. This warranty covers defects in material and workmanship, provided the product is used and maintained correctly.

What's Covered

- **Repair or Replacement:** If a product is defective due to workmanship or materials, Reliable will repair or replace it.
- If the defective product is no longer available, we will replace it with a similar product of equal or greater value.
- Replacements or repairs may be new or refurbished.

What's Not Covered

- Damage from improper installation, misuse, accidents, or natural disasters.
- Wear and tear from normal use.
- Damage caused by unauthorized repairs or modifications.
- Products without serial numbers or those altered in any way.
- Indirect, consequential, or incidental damages.

How to Claim

To claim a repair or replacement:

1. Contact customer support at support@reliablecorporation.com or 1-800-268-1649.
2. Provide an original receipt showing you are the original purchaser, and that the product was bought from Reliable or an authorized dealer.
3. You will receive a Return Authorization (RA#) and shipping instructions.

Warranty Limitations

This is the only warranty for Reliable products and overrides any other warranty terms.

For more information, visit our website at reliablecorporation.com.



05032026