

 **RELIABLE**



600VB

The Air Board

600VB
The Air Board
Instruction Manual
English



Do Not Return To Store
Contact Us First

For immediate help with your purchase, please give us a call so that we can resolve your issue.

We can be reached toll-free at 1-800-268-1649 or email support@reliablecorporation.com

Reliable. Getting it Right. For You.

At Reliable, we do what we love, and we take pride in doing it right. You want what's best for the people, places and things that matter in your life—from where you live to what you wear. So do we. That's why we approach every product with a laser-focus on you. In our commitment to quality, functionality, design and customer service, we are continuously innovating to find solutions to better fit your needs. Everything we make looks and feels just right, because it is. We get it right. For you.


For your safety and to fully enjoy the advantages of this product, please take a few minutes to read all the important safeguards and care instructions. Keep this manual handy and review the product warranty for your reference.

Thank you for your purchase. Please share your Reliable product experience by posting an online review on the website from which you purchased. We greatly appreciate it.


How to Assemble and Use

Read All Instructions Before Use


1. Align the iron rest to the back of the ironing board from below and insert the iron restrails into the slots. Tighten the thumb screws to secure the iron rest.



2. Unfold: Hold the ironing board vertically, with the end down, place one foot on the wheel (8); press the handle (5) located below the board and lift the work surface by pulling with your foot towards you. Raise to the desired height.



3. Place the ironing board cover on the ironing surface frame. Stretch the cover over the corners, sides and ironing board, making sure the cover is rolled up tightly over the pressing surface. Pull the cord at the end of the cover downward to hold it firmly on the board. Make sure to apply enough force to the cords to remove surface wrinkles.
4. Place the iron station or household iron on the iron rest.
5. Insert the power plug into the power outlet, wait for a few minutes until the working surface is warmed up.



6. Connect the pedal to its socket (optional) (7).
7. Push the switch (A) to the "I" position to turn on the appliance.
8. Position the switch (B) down to work with the switches and up to work with the pedal (optional).
9. You can choose the "I" position for the suction, "O" for neutral and "II" for the blowing function (C).
10. Wait a few minutes for the work surface to warm up.
11. Start ironing.
12. To activate the suction or blowing function, simply press the pedal (optional) (B up) or with the switches (B) down.
13. You can use the suction or blowing function at the same time as you iron, or you can use it after ironing (for very delicate fabrics this might be preferable).
14. After you have finished ironing, leave the ironing board on for a few minutes to remove any traces of moisture. Before folding the board, turn on the suction to cool it down. This operation will ensure a long life for your board, completely removing any water residue.
15. Folding: Turn the on/off switch (A) to the off position, remove the power plug from the power outlet. Remove the kettle and iron from the support (3), remove the support (3) and make sure that there are no clothes on the work surface and/or linen rest (4).
16. To fold the board, proceed as for opening, but in reverse and remembering to press the release lever. It is absolutely forbidden to fold the ironing board before removing the iron or the ironing unit from the iron rest. When folded, the board is very stable. It does not need to be placed against a wall.

For household and light commercial use only. Save these instructions in a safe place for future reference.

Attention

Important:

When you want to dispose of the appliance, NEVER throw it in the garbage. Instead, go to your closest recycling station or waste collection centre for treatment

Features

- Powerful vacuum cleaner with suction/blowing
- Robust frame
- Integrated heating element
- Large pressing surface
- Quickly folds for easy storage and transport

Maintenance

We suggest checking the ironing board cover (7) periodically and, if it is necessary, replacing it with an original one (part #600VBACR).

Specifications



Electrical 120V/Single Phase

Frequency 60HZ

Wattage 650W

Working surface 45 x125 cm

Description of the Air Board



- | | |
|-----------------|--------------------------------|
| 1. Foot pedal | 6. Legs |
| 2. Switches | 7. Foot pedal socket |
| 3. Iron Rest | 8. Wheel |
| 4. Laundry Rack | 9. Ironing surface |
| 5. Handle | 10. Motor |
| | 11. Conex® heat resistant zone |

Before using the ironing board, read the instructions carefully and keep them for future reference

Important Safeguards

1. The board height lever must never be released when the iron is on the iron rest (C) to avoid the iron falling and sudden closure of the board.
2. The appliance must be used in a dry place only. Turn the appliance on when in the working position only.
3. The appliance must be powered with alternating current at the voltage given on the rating plate under the ironing board only. The wall socket and extension cable must support 16A and must be efficiently earthed.
4. The appliance power cable must be kept away from hot parts of the iron.
5. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
6. Never insert objects into apertures in the appliance.
7. Never use the board with damaged extension cable or plugs, with serious damage (for example, after being dropped) or when malfunctioning.
8. All repairs must be carried out by an authorised service centre only. Repairs performed by unqualified persons are dangerous and invalidate the guarantee. All components of the appliance must be replaced with original spare parts only.
9. If the power cable is damaged, it must be replaced by the manufacturer or its service department, or in any case by qualified personnel, so as to prevent all risks.
10. Unplug from the mains socket before leaving the room, before cleaning or maintenance and after use.
11. Never unplug by pulling on the cable.
12. The manufacturer is not liable for damage to persons, things or animals deriving from inappropriate or incorrect use of the appliance.
13. Some parts of the board, especially those next to the ironing surface, become very hot. Do not touch them.
14. The iron's steam generator must be filled only after having unplugged the board from the power socket.
15. Never expose the appliance to the rain, sun, etc.

**Important Information for Correct Disposal of the Product in Accordance
with EC Directive 2000/96/EC**



At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from

inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed out wheeled dustbin.



Reliable Corporation ("Reliable") warrants to original purchaser of its products that every product sold by Reliable (a "Reliable Product") is free from defects in material and workmanship for a period of one year from the date of purchase if properly used and maintained. Subject to the conditions and limitations set forth below, Reliable will either repair or replace any part of a Reliable Product that proves defective by reason of improper workmanship or materials. If the defective Reliable Product is no longer available and cannot be repaired effectively or replaced with an identical model, Reliable shall replace the defective Reliable Product with a current Reliable Product of equal or greater value. Repaired parts or replacement products will be provided by Reliable on an exchange basis, and will be either new or refurbished to be functionally equivalent to new. If Reliable is unable to repair or replace a Reliable Product, it will refund the current value of that Reliable Product at the time the warranty claim is made.

This limited warranty does not cover any damage to a Reliable Product that results from improper installation, accident, abuse, misuse, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, wear and tear resulting from normal use of the product, or any unauthorized disassembly, repair, or modification. This limited warranty does not extend to any indirect, consequential or incidental damages that may be suffered by a user or from the use of a Reliable Product, including without limitation, any liability for third party claims for damage, and is limited to the amount paid by the original purchaser Reliable Product with respect to which this limited warranty protection applies. This limited warranty does not apply with respect to products that have been altered or which are missing serial numbers or for products not purchased directly from Reliable or a dealer authorized by us to sell Reliable Products.

This limited warranty is the only warranty that applies to any Reliable Product, supersedes any and all terms that may be contained in any other document or purchase order and may not be altered or amended except expressly in writing by Reliable.

To obtain a repair or replacement under the terms of this warranty, please contact our customer service group at 1-800-268-1649 or at support@reliablecorporation.com.

You will be required to submit an original receipt via e-mail. The receipt must reflect that you are the original purchaser, the product was bought directly from us or from an authorized Reliable dealer and that the warranty claim is being made within the warranty period. You will be issued a return authorization number (RA#) and asked to ship the defective product together with proof of purchase and RA#, prepaid insured to the following address:

Reliable Corporation, 5-100 Wingold Avenue, Toronto, ON M6B 4K7. Freight collect shipments will be refused. The risk of loss or damage in transit will be borne by the customer. Once Reliable receives the defective product, it will initiate the repair or replacement process.

If you have any questions regarding this warranty, you may write to:

Reliable Corporation
100 Wingold Avenue, Unit 5
Toronto, Ontario
Canada M6B 4K7
www.reliablecorporation.com



28072025